SET UP ON FIRE TV.

FIRE TV, FIRE STICK & FIRE TV CUBE · 26 EASY STEPS · ABOUT 10 MINUTES

YOU NEED


Your TV remote and Wi-Fi

THE CODE

5181788

YOUR LOGIN


Username & password from your welcome message



01

OPEN SETTINGS


Press **Home**, then **LEFT twice** to open the menu. Select **Settings** at the bottom.



02

OPEN MY FIRE TV


Select **My Fire TV**.



03

OPEN ABOUT


Select **About**.



04

TURN ON DEVELOPER OPTIONS


Press OK on your device name (top of the list) **7 times**, until it says **"You are now a developer"**. "Already a developer" means you're set.



05

SEARCH FOR DOWNLOADER


Press **Home**, go to the 🔍 search, type **downloader** and select it.



06

PICK THE ORANGE DOWNLOADER


Select the **orange Downloader** app (not the look-alike next to it).



07

DOWNLOAD IT

Select **Download**. It opens by itself; close any pop-ups.



08

GO TO THE ADDRESS BAR


Downloader opens on a news page (ignore the ads). **Hold UP** until the white bar at the top is outlined in yellow, then press OK.



09

ENTER THE PROTV CODE


Type **5181788** and select **Next**.



10

LET DOWNLOADER INSTALL APPS

The first time, a message says your TV isn't allowed to install unknown apps. Select **Settings**, then **Install unknown apps**, and turn **Downloader ON**. Press **BACK** twice to get back to Downloader.



11

INSTALL PROTV

When the download finishes, select **Install**.



12

CONFIRM INSTALL


Select **INSTALL** (it starts on Cancel).



13

SELECT DONE


Select **DONE**.



14

DELETE THE INSTALLER FILE


Select **Delete**, then **Delete** again. This only frees up space.



15

PUT PROTV AT THE FRONT


Press **Home**, find **ProTV Streams** at the end of your apps row, **hold OK** and choose **Move to front**.



16

OPEN PROTV AND ADD YOUR PLAYLIST


Open **ProTV Streams** and select **Add playlist**.



17

CHOOSE PROTV STREAMS


Select **ProTV Streams**.



18

SIGN IN


Enter the **username** and **password** we sent you (capitals matter). Leave both boxes ticked and select **Next** on the right.



19

WAIT FOR YOUR CHANNELS TO LOAD


Give it about a minute, then select **Done**. Wait for the TV guide to open.



20

OPEN THE APP'S SETTINGS


Press **LEFT twice** to open the menu and select **Settings** at the bottom.



21

OPEN PLAYLISTS


Select **Playlists**.



22

OPEN YOUR PLAYLIST


Select your **ProTV Streams** playlist.



23

TURN ON "UPDATE ON APP START"


Scroll down and turn on **Update on app start**.



24

OPEN EPG (THE TV GUIDE SETTINGS)


Press **BACK** twice and select **EPG**.



25

TURN ON "UPDATE ON APP START" HERE TOO

Turn on **Update on app start** here too.



26

YOU'RE ALL SET

Press **BACK** twice to close Settings. To watch, pick a channel and press **OK**. Press **LEFT twice** any time for Movies, Shows and the Sports Guide.